Fire Safety During Holidays and Winter Time

Residential fires take their toll every day, every year, in lost lives, injuries, and destroyed property. The fact is that many conditions that cause house fires can be avoided or prevented by homeowners. Taking the time for some simple precautions, preventive inspections, and concrete planning can help prevent fire in the home - and can save property and lives should disaster strike.

• **Check holiday lights** for fraying or broken wires and plugs. Follow the manufacturer's guidelines when joining multiple strands together, as a fire hazard could result from overload. Enjoy indoor holiday lighting only while someone is home, and turn them off before going to bed at night.



- Candles add a welcome festive feeling, and should be placed in stable holders and located away from curtains, drafts, pets, and children. Never leave burning candles unattended, even for a short time.
- Live Christmas trees should be kept in a water-filled stand and checked daily for dehydration. Needles should not easily break off a freshly-cut tree. Brown needles or lots of fallen needles indicate a dangerously dried-out tree which should be discarded immediately. Always use nonflammable decorations in the home, and never use lights on a dried-out tree.



- All electrical devices including lamps, appliances, and electronics should be checked for frayed cords, loose or broken plugs, and exposed wiring Never run electrical wires, including extension cords, under carpet or rugs as this creates a fire hazard.
- Fireplaces should be checked by a professional chimney sweep each year
 and cleaned if necessary to prevent a dangerous buildup of creosote, which
 can cause a flash fire in the chimney. Cracks in masonry chimneys should be
 repaired, and spark arresters inspected to ensure they are in good condition
 and free of debris.




 When using space heaters, keep them away from beds and bedding, curtains, papers - anything flammable. Always follow the manufacturer's instructions for use. Space heaters should not be left unattended or where a child or pet could knock them over.

- **Use smoke detectors** with fresh batteries unless they are hard-wired to your home's electrical system. Smoke detectors should be installed high on walls or on ceilings on every level of the home, inside each bedroom, and outside every sleeping area. Statistics show that nearly 60% of home fire fatalities occur in homes without working smoke alarms. Most municipalities now require the use of working smoke detectors in both single and multifamily residences.
- Children should not have access to or be allowed to play with matches, lighters, or candles. Flammable materials such as gasoline, kerosene, or propane should always be stored outside of and away from the house.



- **Kitchen fires know no season**. According to the U.S. National Fire Protection Association, 46% of reported home fires in 2015 were caused by cooking. Grease spills, items left unattended on the stove or in the oven, and food left in toasters or toaster ovens can catch fire quickly. Don't wear loose fitting clothing, especially with long sleeves, around the stove. Handles of pots and pans should be turned away from the front of the stove to prevent accidental contact. Keep an all-purpose fire extinguisher within easy reach. Extinguishers specifically formulated for grease and cooking fuel fires are available and can supplement an all-purpose extinguisher.
- Have an escape plan. This is one of the most important measures to prevent death in a fire. Visit ready.gov for detailed information on how to make a plan. Local fire departments can also provide recommendations on

escape planning and preparedness. In addition, all family members should know how to dial 911 in case of a fire or other emergency.



Your New Era Remodeling & Repairs wishes you and your family a happy and safe holiday season.